

## Batteries, Charger and Rubber Bands

### Batteries and Charger

Batteries and a charger are used with myoelectric prostheses to supply the energy for motion of the wrist and/or terminal device (hand or hook).



### Rubber Bands

Rubber bands are used to provide tension or grip strength for the prosthetic hook. The patient can select the number of rubber bands needed to perform his or her daily activities.



Photos courtesy of Fillauer Companies